



How To: Remove Front Ceiling Light

Courtesy of **gawako_syd**

1. Use a flash light (torch) to help you see were the two latches on each side.
2. The location of these two latches are about an inch from each side.
3. You need to use a screw driver and insert it between the gap of the ceiling light and the headliner.
4. Do this at the side towards the windscreen and not at the side facing the rear.
5. Once you inserted the screw driver apply a SLIGHT force towards the rear, be careful not to put too much force as this could damage the headliner.
6. Use the torch to see where exactly the location of the anchorage.
7. Once you found the latches everything is just like picking a door using a credit card