



How to: Reset service light

Turn your ignition on, by pressing your Start button for 3 seconds, but not depressing the clutch.

Hold the small trip reset button (in your instrument binacle) in for about 5 seconds, the service menu will now be available.

Scroll through the various service options using the up/down buttons on the left hand stalk, and reset as appropriate, using the button on the end (might have to hold it down for a few seconds, until the animation finishes?).